
a ASKO



INSTRUCTIONS FOR USE

TD75.B2XX

Tumble dryer T208C.W.AU

Carefully read the instructions for use before using the dryer.

Dear Customer,

We thank you for purchasing this quality ASKO product.

We hope it meets all your expectations. Scandinavian design combines pure lines, everyday functionality, and high quality. These are the key characteristics of all our products, and the reason why they are highly appreciated across the globe.

We kindly recommend you to read these instructions before using the appliance for the first time. The instruction manual also includes information on how you can help protect the environment.

TABLE OF CONTENTS

Safety precautions	3
Dryer description	7
Before using the appliance for the first time	8
Installation and connection	9
Advices before drying	19
Drying process, step by step (1 – 7)	21
System settings	29

Cleaning and maintenance	32
Errors – what to do?	38
Servicing	42
Program table	45
Disposal	46
Quick guide	47

The following symbols are used throughout the manual and they have the following meanings:

-`ģ´-	Information, advice, tip, or recommendation	Warning – danger of hot surface
\triangle	Warning – general danger	Warning – danger of fire
	Warning – danger of electric shock	

SAFETY PRECAUTIONS

GENERAL

Please read the instruction manual and save it for future reference.

- Please do not use the tumble dryer if you have not read and understood these instructions or use first.
- Failure to observe the instructions for use or inappropriate use of the tumble dryer may result in damage to the laundry or appliance, or injury to the user.
- Instructions for use are available on our website at www.asko.com.
- Your dryer is intended solely for household use.
- Before connecting the dryer to the power mains, please read carefully the instructions for use that describe the dryer and its correct and safe use. The instructions apply to several appliance types or models; thus, settings or equipment may be described herein which is not available in your dryer.
- Leave any repairs and similar tasks on the dryer to an expert. Unprofessional repair may result in an accident or major malfunction.
- After installation, the dryer should stand still for two hours before it is connected to the power mains.
- At least two persons are required to install the tumble dryer on top of a washing machine.
- The dryer shall not be connected to the power mains using an extension cord.
- Do not connect the tumble dryer to an electrical outlet intended for an electric shaver or hair dryer.
- A If the power cord is damaged, it has to be replaced by the manufacturer, an authorized service technician, or a similarly qualified person, in order to avoid any hazards.
- A The appliance shall not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- After the drying process, unplug the dryer power cord from the power outlet.
- In case of incorrect appliance connection, incorrect use, or servicing by an unauthorized person, the user shall bear the cost of any damage.
- Air in the dryer environment should not contain dust particles. The air where the dryer is installed should be thoroughly ventilated to prevent reverse flow of gases released from the gas appliances with open fire (e.g. fireplaces).
- Do not evacuate the air from the dryer through channels used for appliances or devices that use natural gas or other fuels for their operation (only applies to the evacuation dryer).

- Do not dry unwashed laundry in the dryer.
- Laundry stained with oil, acetone, alcohol, oil derivatives, stain removers, turpentine, wax, and wax removers should be washed in a washing machine with hot water and detergent before it is dried in the dryer.
- Clothing that includes latex, rubber parts, shower and bathing caps, and laundry or covers with rubber foam shall not be dried in the dryer.
- Use laundry conditioners or similar products in compliance with manufacturer's instructions.
- Oil-affected items can ignite spontaneously, especially when exposed to heat sources such as in a tumble dryer. The items become warm, causing an oxidation reaction in the oil. Oxidation creates heat. If the heat cannot escape, the items can become hot enough to catch fire. Piling, stacking or storing oil-affected items can prevent heat from escaping and so create a fire hazard.
- If it is unavoidable that fabrics that contain vegetable or cooking oil or have been contaminated by hair care products shall be placed in a tumble dryer they should first be washed in hot water with extra detergent this will reduce, but not eliminate, the hazard.
- Do not place the dryer behind lockable or sliding door, or door with a hinge on the opposite side of the dryer door hinge. Install the dryer in such way that the door can always be freely opened.
- Never block the air vents.
- Do not place the dryer on a carpet with long fibres as this may impede air circulation.
- The air in the room where the dryer is installed may not contain dust particles.
- Make sure the fibres do not accumulate around the dryer.
- A Remove all objects such as lighters and matches from the pockets.
- After installation, wait for 24 hours before using the appliance. If the dryer has to be laid down on one of the sides during transport or servicing, place it with its left side, viewing from the appliance front, downwards (only applies to dryers with a heat pump).
- The appliance shall not be in contact with a wall or adjacent furniture.
- If the dryer is connected to an air exhaust system already used for another appliance, a non-return valve must be installed. Reverse flow into the dryer could damage the appliance, and the non-return valve prevents such reverse flow (only applies to evacuation dryer).
- A float will switch off the appliance if the condensed water pipe is clogged or if there is a risk of overflowing of the condensed water accumulated in the condensed water tank (only applies to condenser dryers and dryers with a heat pump).

- If you wish to move the dryer or store it in a non-heated room during winter, it is essential that you first empty the condensed water tank (only applies to the condenser dryers and dryers with a heat pump).
- Maximum drying capacity in kg (for the Cotton program) is indicated on the rating plate.


SAFETY

- A Only use the dryer to dry laundry that was washed with water. Do not dry any laundry that was washed or cleaned with flammable cleaners or substances (such as gasoline, trichloroethylene etc.) as this may result in an explosion.
- If you have cleaned your clothes with industrial cleaners or chemical substances, do not dry them in the dryer.
- If the air exhaust hose is connected to an opening in the wall, influx of cool air may be prevented by installing a ventilation grille (only applies to evacuation dryer).
- The air exhaust hose shall not be connected to an active chimney used to evacuate smoke or waste gases; into a shaft intended for ventilating rooms with combustion equipment; or into a chimney used by third parties. If smoke or waste gases return to the room where the dryer is installed, there is a danger of poisoning (only applies to evacuation dryer).
- The dryer is protected with an automatic switch-off system in case of overheating. The system switches off the heater if the temperature is too high (only applies to evacuation and condenser dryer).
- If the net filter is clogged, the automatic heater switch-off device can be triggered. See chapter "CLEANING AND MAINTENANCE" (only applies to evacuation and condenser dryer).
- MARNING! The back of the dryer may get very hot during operation. Wait for the dryer to cool down completely before touching its back side. (Observe the instructions in the chapter "INSTALLATION AND CONNECTION")
- A Never stop a drying cycle or do not open the door before the end of the program. If you do so for any reason, be careful when taking the laundry from the drum as it can still be very hot and there is a risk of burning.
 Quickly remove the laundry from the drum and spread it to allow it to cool down as quickly as possible.

CHILD SAFETY

- Do not allow the children to play with the dryer.
- Prevent your children and pets to enter the dryer drum.
- Before closing the dryer door and running the program, make sure there is nothing except laundry in the drum (e.g. if a child climbed into the dryer drum and closed the door from the inside).
- Activate the child lock. See chapter "SYSTEM SETTINGS", section Child Lock.
- Do not let children younger than three years to come near the dryer, unless they are under constant supervision.
- The dryer is made in compliance with all relevant safety standards. This dryer may be used by children aged 8 years and above and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge, but only if they are supervised during the use of the appliance, if they have been provided relevant instructions regarding safe use of the dryer, and if they understand the hazards of inappropriate use. Make sure children do not play with the appliance. Make sure the children do not clean the dryer or perform any maintenance tasks without supervision.

DRYER DESCRIPTION



- Main switch (ON/OFF) 1.
- 2. Program selector knob
- 3. Display unit
- Program selector buttons
 Button (start/pause)
- 6. Rating plate with information about the dryer (on the inside of the drying machine door)
- 7. QR and AUID code (on the inside of the drying machine door)
- Dryer door 8.
- 9. Door net filter
- **10.** Condensate tank (depending on the model)
- **11.** Condenser unit
- 12. Air vents

BEFORE USING THE APPLIANCE FOR THE FIRST TIME


PACKAGING

Remove all packaging.

Please sort the materials in compliance with local recommendations (see chapter "DISPOSAL").

CLEANING

Disconnect the dryer from the power mains and open the door towards you. Clean the dryer drum with a damp cloth and a mild detergent.



 $\dot{\dot{\phi}}$ No program can be started while the door is open.

CHOOSING THE LANGUAGE

When the dryer is connected (see chapter "INSTALLATION AND CONNECTION") and switched on for the first time, choose the preferred language:

- 1. Press the button 2 or the program selector knob to scroll the list of languages. Confirm your selection by pressing the OK button.
- Press the "Finalise" (Finalize) button to confirm your selection. For further drying process, see chapter "DRYING PROCESS, STEP BY STEP (1–7)".

 \overline{Q}^{-} When you run the dryer for the first time, or if the dryer has been out of use for a long time, slight hitting noise may appear. This is normal and it will disappear after a few drying cycles.

INSTALLATION AND CONNECTION

DRYER PLACEMENT

The dryer can be either free standing or installed on top of a washing machine.

The dryer emits heat. Therefore, do not place it in a very small room, as the drying process may be longer due to limited amount of ambient air.

- Do not place the dryer in a room where temperature can drop below 0 °C, as the machine may not operate correctly at such low temperatures or freeze with damages as consequences. For optimum dryer operation, install it in a room with adequate ventilation and a temperature between 10 °C and 25 °C.


 \triangle Do not place the dryer behind lockable or sliding door, or door with a hinge on the opposite side of the dryer door hinge. Install the dryer in such way that the door can always be freely opened.

 $\dot{\nabla}$ Never block the air vents.

 \triangle Do not place the dryer on a carpet with long fibres as this may impede air circulation.

 $\dot{\gamma}$ If the appliance is installed on a plinth or a similar structure, then the appliance must be fixed to it, to avoid the risk of falling. ASKO original accessories are available for this


purpose, complete with fixing instructions.




Free-standing appliance

The dryer may be placed adjacent to a washing machine.


To prevent sliding, use a non-slide mat or install the supplied vacuum feet onto both front feet.






Place the dryer so that it is stable. Use a spirit level to level the dryer in longitudinal and traverse direction by rotating the adjustable feet using a No. 22 spanner (max. 15 mm). Then, firmly tighten the jam nuts (counter nuts) by rotating them towards the appliance bottom using a No. 17 spanner **1**.

Clearance around the dryer for optimum operation




 \overline{O}^{-1} The appliance shall not be in contact with a wall or adjacent furniture. For optimum operation of the drying machine, it is recommended to consider the deviation from the wall, as shown in picture.

Opening the door of the dryer (top view).



Stacking on top of a washing machine

To stack the dryer on top of a washing machine, use the extra vacuum feet and the tipping guard (A+B), supplied in the cardboard box in the dryer drum. Tipping guard part B is designed to fit on ASKO washing machines and it may be hard or impossible to mount on appliances of other brands. If the washing machine and dryer are not of matching dimensions or if you have installed a hidden helper between the two appliances, then binding plates are available as optional accessories at the service center (... available only for HH (acessory Hidden Helpers) and TD75 stacked on top of WM80 or WM85; not intended for any other combinations).




All ASKO washing machines will bear the weight of the dryer.

 $\dot{\nabla}$ Washing machine on which you wish to install the dryer must be able to bear the weight of the dryer (see washing machine's rating plate or technical information).

 $\dot{\phi}$ At least two persons are required to install the tumble dryer on top of a washing machine.


How to stack a dryer onto the washing machine (ASKO):


There is a cardboard box in the dryer drum, containing the vacuum feet and the tipping guard.




CHANGING THE DOOR OPENING DIRECTION

To change the direction of door opening, proceed as follows.





BUILT-IN



ASKO dryers can be installed beneath a cabinet or worktop with a minimum height of 864 mm. There must be a gap of about 12 mm all around the machine and a minimum gap of 25 mm between the rear edge of the machine top panel and the back wall. The opening width must be at least 622 mm. The condensing models work best when they have good air circulation.

Install the dryer so the condensed water will continuously flow into a drain or sink, you will need a drain outlet behind the unit. The maximum drain height is 1016 mm.

 $\dot{\phi}$ The height adjustment for the dryer is 850 mm to 876 mm. Do not raise it higher than 876 mm.

 $\dot{\phi}$ It is very important to avoid a buildup of heat.

 $\dot{\varphi}$ The warm air which is expelled from the rear of the dryer must be able to dissipate.

 $\dot{\dot{\varphi}}$ Warm air which cannot dissipate could cause a fault.

A buildup of heat could be avoided by:

• Creating a gap for the dryer in the kitchen furniture plinth facing.

• Creating ventilation gaps in the kitchen unit. When build under, drying times may be longer.

not possible to install the dryer anywhere else, then the refrigeration appliance must be sealed off from the dryer.


Ventilation Requirements of ASKO laundry concept or closet installation

ASKO's front panel controls make it possible to install the washers and dryers in a cabinet or closet.

Make sure there is clearance between appliances and cabinet or wall and 25 mm minimum clearance between the rear edge of the appliance top panel and the cabinet or wall.

When closet or cabinet is closed by the door, we recommend louvered doors, to ensure proper ventilation particularly for condenser dryers.

Otherwise there must be ventilation openings on the door. See illustration of dimension for ventilation openings below:



 $\overline{\ }$ Ensure the dryer door can be opened without hindrance after installation.


 $\overline{\ }$ The cool air intake panel at the front of the dryer must not be blocked or covered. Doing so could cause a fault.

 \triangle Disregarding of instructions influences on appliance performance and may also result in failure of the appliance.

DRAINING THE CONDENSATE

The moisture from the laundry is extracted in the condenser unit and accumulated in the condensate tank. Condensate tank has to be emptied regularly (see chapter "CLEANING AND MAINTENANCE").

To simplified and avoid emptying and interruption of the drying cycle due to full condensate tank, run the condensate discharge tube located at the back of the appliance directly into a drain (see chapter "SYSTEM SETTINGS/ Condensed water").



 $\dot{\dot{V}}$ Do not pull the drain hose, and make sure it is not under tension, clamped, or bent.

If you decide to run the condensate drain hose into a drain, siphon, or washbasin, make sure the hose is securely fastened. This will prevent any water spillage that could result in unexpected damage.

Always use hoses that are attached to the appliance.

If the dryer is connected to an air exhaust system already used for another appliance, a non-return valve must be installed. Return flow into the dryer could damage the appliance and the non-return valve prevents such flow.

CONNECTING TO THE POWER MAINS

After installation, the dryer should stand still for two hours before it is connected to the power mains.

Connect the appliance to an earthed power outlet. After installation, the wall outlet should be freely accessible. The outlet should be fitted with an earth contact (in compliance with the relevant regulations).

Connection upon delivery

	DXX.XXXXX	
Art.No.:	XXXXXX/XX	Ser.No.: XXXXXXXX
	XXXX W 🖨 X	X kg
IPX4 XX	Hz	

Information about your dryer is indicated on the rating (type) plate.

Use the type A differential current protection switch.


 \triangle The dryer shall not be connected to the power mains using an extension cord.


 $\dot{\phi}$ Do not connect the tumble dryer to an electrical outlet intended for an electric shaver or hair dryer.

 $\dot{\phi}$ Any repair and maintenance pertaining to safety or performance should be done by trained experts.

ASKO LAUNDRY CARE - HIDDEN HELPERS*







Laundry care ironing board

The ironing board is a clever solution. It is always handy when you need to iron your clothes, and it can be easily, safely and invisibly stored away when not in use.

.....

It can be installed between your washer and dryer, or on top of one of them.

.....

Laundry care double

A wire basket and pull-out shelf. It can be used as an additional surface for folding clothes, sorting socks and for storage. The basket is useful for removing and carrying laundry to the wardrobe or workbench for ironing and folding.

It can be installed between your washer and dryer, or on top of one of them.

.....

Laundry care single

Pull-out shelf. It can be used as an additional surface when folding clothes and sorting socks or for storage. It also makes loading and unloading your laundry much easier.

It can be installed between your washer and dryer.




Laundry care basket

A large pull-out basket that is easily accessible via a push-pull door opening. Useful for removing laundry and carrying it to the wardrobe or workbench for ironing and folding.

It can be installed between your washer and dryer, or on top of one of them.

Pedestal drawer with shelf

A useful storage drawer with a height of 30 cm. Ideal for storing your detergent, softener, coat hangers, pegs, user manuals and other useful items in the laundry area. The drawer also comes with a shelf for easy loading and unloading of your laundry.



Laundry care plinth Thanks to the stainless steel plinth, your appliance will be raised by 30 cm, which makes loading and unloading of laundry easier.

*AVAILABILITY DEPENDING ON MARKET

DENOMINATION	ART. No.
IRONING BOARD HI1153 White	576552
IRONING BOARD HI1153 Stainless steel	732756
IRONING BOARD HI1153 Titanium	576553
LAUNDRY CARE DOUBLE HDB1153 White	576554
LAUNDRY CARE DOUBLE HDB1153 Stainless steel	732757
LAUNDRY CARE DOUBLE HDB1153 Titanium	576555
LAUNDRY CARE SINGLE HSS1053 White	576730
LAUNDRY CARE SINGLE HSS1053 Titanium	576732
LAUNDRY CARE HB1153 White	576733
PEDESTAL DRAWER W. SHELF HPS5323 White (only 8 or 9 kg models)	576735
PEDESTAL DRAWER W. SHELF HPS5323 Stainless steel (only 8 or 9 kg models)	576737
STAINLESS STEEL PLINTH HPL530S FOR 8 AND 9 kg MODELS	441663
STAINLESS STEEL PLINTH HPL830S FOR 11 AND 12 kg MODELS	445501

ADVICES BEFORE DRYING

This chapter includes several advices on how to prepare the laundry from drying.

LAUNDRY SORTING

Sort the laundry according to:

- type,
- fabric thickness.

For the most even drying, make sure the laundry is made of a similar material.

CLOTHING

- 1. Close the buttons, zips, and hook-and-loop fasteners, so that they do not damage the fabric.
- 2. Turn the pockets inside out.
- Place very sensitive clothes in a special-purpose laundry washing bag. (The special purpose laundry bag is available as an optional accessory in general stores.)



 $\dot{\gamma}$ Laundry to be dried in the dryer should be spun at a minimum of 1000 rpm. Higher spinning speeds will save energy and cut drying time.

 $\dot{\phi}$ If you decide to dry only one large item, we recommend drying it separately from smaller items of laundry.

LAUNDRY SYMBOLS Observe the laundry symbols.

Textile maintenance symbols:

~~~~ N	/ashing	
Normal		Delicate
90	Max. washing temperature 90 $^\circ\mathrm{C}$	<u>90</u>
60	Max. washing temperature 60 $^\circ\text{C}$	
40/	Max. washing temperature 40 $^\circ\mathrm{C}$	40
30/	Max. washing temperature 30 °C	30
tund	Hand wash only	
$\bowtie$	Do not wash	
В	leaching	
	Bleaching in cool water	
$\bowtie$	Bleaching not allowed	
	ry cleaning	
A	Dry cleaning with all agents	
P	Perchloroethylene R11, R113, per	troleum
F	Dry cleaning in kerosene, pure alo and R113	cohol,
$\bigotimes$	Dry cleaning not allowed	
	oning	
	Ironing with a hot iron with a maxim temperature of 200 °C	mum
•••	Ironing with a hot iron with a maximum temperature of 150°C	mum
•	Ironing with a warm iron with a matemperature of 110°C	iximum
$\mathbb{X}$	Ironing not allowed	
Na	atural drying	
	Drying on a flat surface	
	Drying without prior spinning	
	Drying on a clothes line or a hang	er
π	umble drying	
$\overline{\boldsymbol{\cdot}}$	Drying at high temperatures	
$\bigcirc$	Drying at low temperatures	
$\boxtimes$	Tumble drying not allowed	

MATERIALS (FABRICS) SUITABLE FOR DRYING IN A TUMBLE DRYER O O Material is suitable for tumble drying. Clothes dried in a tumble dryer will be softer and lighter than air-dried clothes.

- 'Ó'- The dryer does not cause any considerable wear of the fabric. The lint collected in the lint filter consists of dust and fabric fragments collected during the use of the laundry.

MATERIALS (FABRICS) THAT MAY NOT BE DRIED IN A TUMBLE DRYER This symbol means that the material is not suitable for drying in a tumble dryer.

#### Never tumble dry the following:

- clothing that was chemically cleaned (or drycleaned) at home,
- foam,
- glass fibres.

# DRYING PROCESS, STEP BY STEP (1 – 7)

# STEP 1: SORT THE FABRICS

See chapter "ADVICES BEFORE DRYING"

 $-\dot{\phi}$  Empty the pockets. Coins, nails etc. could damage the machine and the fabric.

## STEP 2: TURN ON THE MAIN SWITCH.




Turning on Press the () on/off button.

Turning off Press the () on/off button.

## STEP 3: OPEN THE DRYER DOOR AND INSERT THE LAUNDRY.

Open the dryer door towards you.



Place the laundry into the empty dryer drum. Make sure there aren't any other objects among the laundry, such a detergent ball.

Such objects could melt and cause damage to the dryer or your laundry.

Do not overload the drum! (See program table and observe your nominal load as indicated on the rating plate.)

If the dryer drum is overloaded, the laundry will be more wrinkled and perhaps unevenly dried.

# STEP 4: CHOOSE THE DRYING PROGRAM.

Choose the program by rotating the program selector knob in either direction.



The program selector knob can be used when arrows appear on the display. Select the program based on the type and remaining moisture of the laundry you wish to dry.

Anticipated program duration is indicated on the display.

Extra program settings can also be selected for each program. See STEP 5.

Choose between the following programs:

Program	Max. kg*	Description
1. AUTO EXTRA DRY (Automatic intensive drying)	8	Use this program for thicker multi-layered non-sensitive cotton laundry. After drying, it will be completely dry and ready to be stored in the cupboard.
2. AUTO DRY	8	Use this program for thicker non-sensitive cotton laundry. After drying, it will be completely dry and ready to be stored in the cupboard.
3. AUTO NORMAL DRY	8	Use this program for thicker non-sensitive cotton laundry of approximately the same thickness. After drying, it will be dry or slightly moist.
4. AUTO IRON DRY	8	Use this program for non-sensitive cotton laundry. After drying, it will be ready for ironing.
5. AUTO SYNTHETICS	3,5	Use this program for sensitive laundry made of a mixture of synthetic and cotton fibres. After drying, the laundry will be slightly moist.
6. BEDDING	5	Use this program for larger items. When the program is complete, they will be completely dry. Adjusted drum rotation prevents the laundry from tangling.
7. QUICK PRO	2	Use this program for non-sensitive laundry washed with a quick program.
8. TIME PROGRAM	4	Use this program for non-sensitive laundry that is still slightly moist and has to be thoroughly dried. In the time program, remaining moisture is not detected automatically. If the laundry is still damp after the program is complete, repeat the program; if it is too dry and therefore creased and rough to touch, the drying time you selected was too long. Program duration can be adjusted from 30 minutes to 4 hours (in 15-minute steps).
9. AIRING	2	This program does not use a heater. Use it to refresh your clothes. Program duration can be adjusted from 15 minutes to 4 hours (in 15-minute steps).


Program	Max. kg*	Description
10. SYSTEM SETTINGS		Use the program selector knob to select System Settings. Confirm the selection by pressing the ENTER (button 2). Then, use the program selector knob to scroll the list of settings. The following can be selected: The following options are available: - Child Lock, - Language (language selection), - Programs (set of programs), - Display (display unit: contrast & logotype), - Sounds, - Condensed water, - Reset. See chapter "SYSTEM SETTINGS".

## * Max. kg dry load

⁻Ý⁻ If your laundry is not dried to the desired dryness level, use extra program settings or use a more suitable program.

## STEP 5: CHOOSING THE PROGRAM SETTINGS

Using the program settings, the drying programs can be further adjusted to your wishes. **Some program settings may not be available for your selected program.** Selected program settings will remain stored after the end of the drying cycle and may be changed subsequently (except for delayed start which is not stored after the drying is complete).



Choose the program settings before pressing the START button. When the drying program is in progress, program settings cannot be changed.

-  $\dot{\Theta}$  Press and hold the button under a program setting to display the information (INFO) about it.

Following are the program settings that may be selected using the buttons 1 to 6:

#### 1. Dryness level (extra dry)

By pressing the button 1, you can choose between extra dryness levels (+, ++, +++). Each time the button is pressed, the final level of laundry dryness and drying time will change.

#### 2. Anti-crease

This function pertains to what happens after the drying cycle. By pressing the button 2, you can choose the duration of the anti-crease program from 0 hours ( $|\rangle^0$  to 4 hours ( $|\rangle^4$ , in 1-hour steps.

#### 3. Load

By pressing the button 3, you can choose between loads of the dryer.

$\bigcirc$	Full load
$\bigcirc$	Small load
$\ominus$	Partial load

Choosing of real load, affect on provided (shown) starting drying time.

#### 4. Lower drying temperature (gentle dry)

Press the button 4 to switch the gentle dry function on (ON) or off (OFF).

#### 5. Timed drying

First, use the program selector knob to select the Timed program. Press the button 5 () to select a drying time from 30 minutes to 4 hours, in 15-minute steps.



Use the button 6 (OK) to confirm the selected drying time. Press the **Start**/ Pause ▶ button to start the drying process.

#### 6. Delay Start

Press the button 6 to choose the Delayed Start when you wish the drying program to start after a certain period of time..

Auto extra dry	+	<b>(</b>  ) ²	θ	&+	Ok	6:00
					<b>.</b>	6
	Delay	ed start (	countdo		Ø	03:50
					5	
					5	

Press the button 6 for to appear. Use the program selector knob or the button 6 to set the delay from 30 minutes to 6 hours in 30-minute steps, and then from 6 hours to 24 hours in 1-hour steps.

Press the button 5 (OK) to confirm the selected Delay Start time. Press the **Start** ► button to start. When the countdown reaches zero, the selected drying program will start automatically.

To <u>cancel</u> the delay and start the drying process immediately, press the button  $5 \bigcirc$ .

When Start delay time is once set, it is not possible to change it; the only possibility is to »Skip it « with pressing on button Ø and immediately continue with chosen program.


- Delayed start cannot be set for the favourite programs.

If you do not take any action for 5 minutes, the display will switch to standby mode.

Press the ON/OFF button to reactivate it. The countdown to the start of the drying cycle will be displayed. If the dryer is in the standby mode, the display will switch on 1 minute before the start of the drying cycle. After the countdown, drying time will be indicated on the display unit.

## STEP 6: CLOSE THE DOOR AND START THE DRYING PROCESS.

Close the dryer door and press the Start/Pause button.



Only after the cooling is complete, can you use the program selector knob to select a new program and press the **Start**/Pause button.

 $\triangle$  The final drying cycle includes a cooling down stage without heater operation. It makes sure the laundry is of suitable temperature at the end of the program and that it can be taken from the dryer without risk of touch hot clothes.

A drying program can be <u>paused</u> using the ON/OFF button. The dryer will switch off. After the dryer is switched on, press the Start button to resume the program.

# STEP 7: END OF PROGRAM

	Cycle c	ompleted	l succes:	sfully	Start   new		Aft the ha
							su
<b>⟨I⟩</b> ^{Anti} creasing	Cycle c	ompleteo	l succes	sfully			lf y op aft an of
	Cycle c	ompleted	l succes	sfully	Start   new	Add   fav?	Af po
						<b>6</b>	a f pro

After the end of the drying program, ne display will indicate that the drying as been finished ("Cycle completed uccessfully").

f you have selected the "Anti-crease" option, the dryer will continue to operate after the end of the drying cycle for the amount of time specified upon selection of this program setting.

After the drying cycle, you have the possibility to save the program as a favorite program (see "Favourite programs").

Clean the net filter in the door

(see chapter "CLEANING AND

MAINTENANCE").

Open the door towards you and remove the laundry from the dryer.



Make sure the dryer drum is empty, then close the door.

5 minutes after the end of the program or last activation, the display will switch off to standby mode in order to save power.

The display will light up again if you press the ON/OFF button or open the dryer door.

-  $\dot{\phi}$  After each drying cycle, clean the net filter in the door and empty the condensate tank. See chapter "CLEANING AND MAINTENANCE".


A clogged net filter and heat pump filter may result in activation of the automatic overheating switch-off device. Clean the filter, wait for the machine to cool down, and try running it again. If the dryer still fails to start, call a service technician.

After the drying process, unplug the dryer power cord from the power outlet.

#### Favourite programs/Add to fav?

Cycle c	omplete	d succes	sfully	Start   new	Add fav?
					: : 6

After the end of the drying program, you can use the button 6 to store the program, including all extra settings, as your favourite program.




Up to 4 favourite programs can be stored.

Choose the favourite program position (number) using the button 2; the most recently used program, including all settings, will be offered. To store a program, confirm with the button 4.

#### Changing a favourite program

If you wish to store a program after the end of the drying cycle, but there is no more room for another favourite program (only 4 favourite program slots are available), then one of the existing stored favourite programs can be substituted with a new one.




Use the button 2 to scroll through the list of Favourite programs. Press the button 4 to confirm the program to be replaced.

Confirm the replacement by pressing the button 5.

If you do not take any action for 5 minutes, the display will switch to standby mode. To activate the display, press the ON/OFF button or open the dryer door.

# SYSTEM SETTINGS




In the main menu, use the program selector knob to select "System Settings". Confirm the selection by pressing the button 2.

Then, use the program selector knob to scroll the list of settings that can be changed.

- Child Lock
- Language
- Programs
- Display unit: contrast and logotype
- Sounds
- · Condensed water
- Reset


Use the button 6 (BACK) to return to "System Settings" or to the main menu.

Press and hold the button under the setting (the "info press function") to display concise information about the setting.



#### PROGRAMS

The main menu includes the entire set of programs that you can choose using the program selector knob. This setting allows only displaying the selected program in the main menu.



Press the button 1 for  $\checkmark$  to appear. Use the program selector knob or the button 1 to select a program. Use the button 3 to set whether this program is to be displayed or not: On  $\checkmark$  / Off  $\blacksquare$ .

Use the button 6 to return to "System Settings".

#### **DISPLAY UNIT**

Display	Contrast Logotype Back Set the Contrast and Logo display.
Contrast	Use the buttons 1 to 5 to set the Contrast.
Logotype	Back Back Use the button 1 to toggle Logo display on ☑ or off □. If you will choose on ☑, the logotype will toggle on display when the washing
	machine will be turned on. Use the button 6 to return to "System Settings".

#### SOUNDS

Choose whether audible signals are switched on or off.

Sound		Mid	Back		
			: : : 4		: : 6


Use the button 1 to switch acoustic signal on  $\square$  or off  $\square$ .

Use the button 4 to choose between the following settings: low, mid, and high. As you scroll through the options, a sample audible signal will be sounded.

Use the button 6 to return to "System Settings".

#### CONDENSED WATER

You can choose between draining condensed water into a condensate tank or directly into the drain.



Press the button 1 for to appear. Use the program selector knob or the button 1 to choose between following: "Tank" – run condensate water into a condensate tank

"Drain" – run condensate water into a drain

If you decide to choose option "Drain", it is necessary to observe how to connect drain hose (see chapter "INSTALLATION AND CONNECTION / Draining the condensate").

Press the button 6 to return to "System Settings".

#### RESET

This means that all settings will return to the default settings and your own settings will be deleted.

Reset default		Yes	Info	Back
		3		6

Confirm the selection by pressing the button 3 (YES).

Press the button 6 to return to "System Settings".

#### SOUNDS

 $\dot{\phi}$  In the initial stage of drying or during drying, the compressor and the pump may cause noise which, however, does not affect the dryer operation.

Humming sound: this is the sound of the compressor unit. The level of noise depends on the program and the drying stage.

<u>Whirring sound:</u> from time to time, the compressor unit is ventilated.

<u>Pumping sound:</u> the pump is pumping the condensate into the condensate tank.

<u>Clicking sound:</u> clicking noise is caused by automatic cleaning of the heat exchanger (compressor).

Rustling water sound: can be heard during automatic cleaning.

Rattling sound: can be heard during drying if laundry has any hard parts (buttons, zippers etc.)

# CLEANING AND MAINTENANCE

 $\dot{\phi}$  Before cleaning, make sure to switch off the appliance and disconnect it from the power mains (unplug the power cord from the outlet).

# CLEANING THE DOOR NET FILTER IN THE DOOR ..... Open the filter housing. Pull out the net filter. ..... Gently scrape the filter to remove the lint lining (fibres and threads). Reinstall the net filter. ..... Close the filter housing. - Make sure the net filter is correctly inserted into the filter housing.


 $\dot{\dot{\sigma}}$  Clean the door net filter after each drying cycle.

 $\dot{\dot{a}}$  Never operate without a door net filter or if the door net filter is damaged.

#### EMPTYING THE CONDENSATE TANK

- ⁽⁻/₂)⁻ After each drying cycle, empty the condensate tank.

If the condensate tank is overflowing the drying program will be paused automatically. A warning will appear on the display unit that the condensate tank has to be emptied. (Disregard this warning if you fed the condensate discharge hose into a drain, siphon, or a sink.)



- 'd'- Water from the condensate tank is not drinkable. If thoroughly filtered, it can be used for ironing.

A Never add chemicals or fragrances into the condensate tank.


 $\dot{\varphi}$  Condensate tank does not require draining if the drain hose is connected directly to a washbasin or a bathroom floor drain (see chapter "INSTALLATION AND CONNECTION/Draining the condensate").

 $\overline{Q}^{-1}$  Before moving the dryer or before storing it in a non-heated room during the winter, the condensate tank has to be emptied.

#### CLEANING OF WATER CONDENSER

- Ġ- Clean the condenser when warning indicate on the display.






During cleaning, some water may be spilled. It is therefore recommended to place an absorbent cloth on the floor. Open the outer cover.







**2** Hold the levers on the inside cover and rotate them upwards. Remove the inside cover.






Rotate the condenser unit lever up. Use the handle to pull out the condenser unit.








 $\dot{\nabla}$  Do not poke into the openings between the condenser unit ribs as this may damage the condenser unit.


 $\dot{\phi}$  Do not wash the condenser unit in a dishwasher.

.....


- Use a soft damp cloth to clean:
- the area in front of the condenser unit where water usually accumulates,
- the area behind the water condenser unit (reach deep into the opening all the way to the rear wall),
- condenser unit housing,
- all gaskets and sealing areas on the condenser unit housing and door.




# ADDITIONAL INFORMATION REGARDING CLEANING



If you have inadvertently removed the **entire** net filter housing in the dryer door, reinstall it in the same position.



Opening on the lower side of the door should occasionally be cleaned with a vacuum cleaner.




If necessary, clean the filter housing and door gasket as well.

### CLEANING THE APPLIANCE EXTERIOR

Clean the appliance exterior and the display unit using a soft damp cotton cloth and water. **Do not use solvents or abrasive cleaners that could damage the appliance** (please observe the recommendations and warnings provided by the manufacturers of the cleaning agents). Wipe all parts of the dryer with a soft cloth until dry.

- 'Ġ- Keep the area around the dryer clean and cool. Dust, heat, and humidity will extend the drying time.



 $\dot{\dot{\phi}}$  Always disconnect the dryer from the power mains before cleaning.

# ERRORS - WHAT TO DO?

Disturbances from the environment (e.g. the power grid) may result in various error reports (see Troubleshooting table). In such case:

- Switch off the appliance, wait for 1 minute, switch the appliance back on, and repeat the drying program.
- If the error persists, call an authorized service center.
- You will be able to solve most of the **problems** in dryer operation by yourself (see troubleshooting table below).
- **Repairs** may only be carried out by an adequately trained person.
- Repair or any warranty claim resulting from incorrect connection or use of the dryer shall not be covered by the warranty. In such cases, the costs of repair shall be charged to the user.

 $\dot{\phi}$  The warranty does not cover the errors or failures resulting from disturbances from the environment (lightning strike, power grid failures, natural disasters etc.).

Problem/error	Cause	What to do?
The machine will not start.	<ul> <li>The main switch is not switched on.</li> </ul>	• Check whether the main switch is on.
	• There is no voltage in the power outlet.	<ul><li>Check the fuse.</li><li>Check if the power cord plug is correctly inserted into the power outlet.</li></ul>
There is voltage in the outlet, but the drum does not spin	<ul> <li>Program was not started in accordance with the instructions.</li> </ul>	<ul> <li>Re-read the instructions for use again.</li> </ul>
 The dryer does not work.	• Door might be open.	Check if the door is closed properly.
	<ul> <li>Condensate tank is full (only applies to condenser dryers and dryers with a heat pump).</li> </ul>	• Empty the condensate tank (see chapter "CLEANING AND MAINTENANCE") (only applies to condenser dryers and dryers with a heat pump).
	<ul> <li>Delayed start might be activated.</li> </ul>	<ul> <li>To cancel the Delayed Start option, press 5 the Skip button.</li> </ul>
The machine stops operating completely during a program.	• The door net filter may be clogged. As a result, the temperature in the dryer rises, which in turn causes overheating, and the dryer switches off.	<ul> <li>Clean the door net filter (see chapter "CLEANING AND MAINTENANCE").</li> <li>Wait for the machine to cool down, and try running it again. If the dryer still fails to start, call service centre.</li> </ul>

Problem/error	Cause	What to do?
Laundry not dried or drying takes too long.	• Filters are not clean.	<ul> <li>Clean the filters (see chapter "CLEANING AND MAINTENANCE").</li> </ul>
	• Dryer is placed in a closed room; room that is too cold; or room that is too small and the air overheats as a result.	<ul> <li>Make sure there is adequate supply of fresh air to the dryer; for example, open the door and/or window.</li> <li>Check if the temperature in the room where the dryer is installed is too high or too low.</li> </ul>
	<ul> <li>Laundry was not sufficiently wrung or spun.</li> </ul>	<ul> <li>If the load is still wet after completed drying cycle, an appropriate drying program should be run again (after cleaning filters).</li> </ul>
	<ul> <li>Amount of laundry dried in the appliance is too large or insufficient.</li> </ul>	• Use a suitable program or extra functions.
	<ul> <li>Laundry (such as bedding) gets tangled.</li> </ul>	<ul> <li>Close the buttons or zippers on the laundry before drying. Select a suitable program (e.g. the bedding program).</li> <li>After the drying process, loosen the laundry and select an additional drying program (e.g. timed drying program).</li> </ul>
Unevenly dried laundry.	<ul> <li>Laundry of varying types and thickness, and excessive amount of laundry.</li> </ul>	• Make sure you have sorted the laundry by type and thickness, whether you have added a suitable amount of laundry to the drum, and whether you have selected a suitable program.
A slight hitting noise appears.	• If the dryer is out of use for a long period of time, the same points of load-bearing elements or components are under stress for a long time, causing temporary deformation.	• The noise will subside without any intervention.
The door opens during drying.	<ul> <li>Excessive load on the door (too much laundry in the drum).</li> </ul>	Reduce the amount of laundry.

#### FAILURE DISPLAY

In case of a failure while a program is in progress, the relevant Error X is indicated on the display unit.



Press and hold the INFO button to display the error description.

Press the 6 EXIT button to return to Main Menu.

Switch off the dryer and turn it back on.

Errors indicated on the display unit (depending on the model) may include the following:

Problem/ error	Error indication on the display	What to do?
Error 0	EO - Please check user manuals or call service.	Control unit failure. Call service centre.
Error 1	E1 - Thermistor fault. Please check user manuals or call service.	Temperature sensor failure. Call service centre.
Error 2	E2 - Please check user manuals or call service.	Communication error. Call service centre.
Error 3	E3 - Pump failure. Please check user manuals or call service.	Failure on the pump for pumping the condensate into the condensate tank Call service centre.
Error 4	E4 - Please clean filters or call service.	Control unit failure. Clean the filters. See chapter "CLEANING AND MAINTENANCE" or call service centre.
Error 6	E6 - Relay failure. Please check user manuals or call service.	Control unit failure. Call service centre.
Error 7	E7 - Door failure. Please check user manuals or call service.	Control unit failure. Call service centre.
Error 8	E8 - Button failure. Please check user manuals or call service.	Control unit failure. Call service centre.
Error 9	E9 - PB/UI software versions are not compatible.	Call service centre.

Error indication on the display	What to do?
EN: Steam tank is empty. Please fill water.	Fill the steam tank with distilled water or condensate. Pour the water through the steam tank filter located in the condensate tank housing. See chapter "BEFORE USING THE APPLIANCE FOR THE FIRST TIME".
EN: Steam tank full.	Stop adding condensate or distilled water.
EN: Please close the door before pressing start.	Close the dryer door before starting or resuming the program.
EN: Option not available at this phase of cycle.	This option is not available. Select an option that is still available.
EN: Cycle was interrupted by power failure. Please resume.	Press the <b>Start</b> /Pause button to restart or resume the program.
EN: Please empty the tank before resuming a cycle.	See chapter "CLEANING AND MAINTENANCE".
EN: Clean door filter.	See chapter "CLEANING AND MAINTENANCE".
EN: Clean the condenser unit.	See chapter "CLEANING AND MAINTENANCE".
EN: Please empty the water tank and clean door filter.	See chapter "CLEANING AND MAINTENANCE".
EN: Child lock is on. Press buttons for 3 sec to unlock.	See chapter "SYSTEM SETTINGS".

### INFORMATION before, during, and after the program (depending on the model)

## SERVICING

BEFORE CALLING A SERVICE TECHNICIAN See the chapters "TROUBLESHOOTING and "CLEANING AND MAINTENANCE" and see if you can resolve the problem yourself.


When you contact a service centre, please state the model (1), type (2), and serial number (3) of your dryer.

Model, type, and serial number are indicated on the rating (type) plate located on the interior side of the dryer door.

QR and AUID code are located on the inside of the drying machine door as well.

 $\triangle$  In case of a failure, only use approved spare parts by authorized manufacturers.

 $\triangle$  Repair or any warranty claim resulting from incorrect connection or use of the dryer shall not be covered by the warranty. In such cases, the costs of repair shall be charged to the user.



<b>2</b>	3 1
ATTAL STATES TO A TYPE: TO XX.XXXXXX ATT.No.: XXXXXXX/XX	MODEL: XXXXXXXXX Ser.No.: XXXXXXXX
XXX V ~ XXXX W 🖨	X kg
IPX4 XX Hz	

### STANDARD TESTS

For the standard test the machine's condensed water hose must be connected to a drain.

Australia	
Drying performance	AS/NZS 2442.1:1996. Auto normal dry, 8 kg cotton, temperature Normal.
Energy declaration	AS/NZS 2442.2:2000. Auto normal dry, 8 kg cotton, temperature Normal.
Test method for noise measurement	IEC 60 704-2-6.


### **TECHNICAL INFORMATION**

Height	850 mm
Width	595 mm
Depth	654 mm
Weight (net)	45 kg
Drum volume	1171
Maximum drying load	See rating plate
Speed	50–55 rpm
Rated power	See rating plate
Drum material	Stainless steel
Housing material	Hot-dip galvanized and powder coated sheet metal, or stainless steel sheet

INSTRUCTIONS FOR LOADING FOR ENERGY PERFORMANCE TESTING ACCORDING TO AS/NZS2442 Instructions for the preparation of standard laundry. Test load mass: 8 kg. Bone Dry mass required: 7,41 kg

ad item	Layout direction	Method of preparation
Bath towels	<	Hold in the middle
Pillow cases	V	Hold in the middle
Pillow cases	٨	Hold in the middle
Shirts	v	Hold for collar of shirts and 1x folded
T - shirts	>	Hold in the middle
Sheets	z	Hold the short side and fold slightly into as many layers as possible, then fold in the shape of the Z and put it in the drum
Undershorts		Wherever
T - shirts	>	Hold in the middle
Tablecloths	<	Hold in the middle
Bath towels	V	Hold in the middle
Shirts	۸	Hold for collar of shirts and 1x folded
Undershorts		Wherever
Sheets	z	Hold the short side and fold slightly into as many layers as possible, then fold in the shape of the Z and put it in the drum
Bath towels	>	Hold in the middle
Shirts	v	Hold for collar of shirts and 1x folded
T - shirts	٨	Hold in the middle
T - shirts	V	Hold in the middle
All Handkerchiefs		Wherever
Sheets	Z	Hold the short side and fold slightly into as many layers as possible, then fold in the shape of the Z and put it in the drum
Undershorts		Wherever
Shirts	<	Hold for collar of shirts and 1x folded
Bath towels	>	Hold in the middle
Tablecloths	٨	Hold in the middle
T - shirts	V	Hold in the middle
Pillow cases	<	Hold in the middle
Pillow cases	>	Hold in the middle
Shirts	۸	Hold for collar of shirts and 1x folded
Tablecloths	V	Hold in the middle
Bath towels	۸	Hold in the middle
	Bath towels Pillow cases Pillow cases Pillow cases Shirts T - shirts Cheets Undershorts T - shirts Tablecloths Bath towels Shirts Undershorts Sheets Sheets Shirts T - shirts T - shirts T - shirts Shirts Undershorts Shirts Shirts I - shirts T - shirts Shirts Bath towels Shirts Bath towels Shirts Bath towels Tablecloths T - shirts Pillow cases Pillow cases Shirts Shirt	Bath towels<Pillow casesVPillow casesAShirtsVT - shirts>SheetsZUndershorts>T - shirts>Tablecloths<

#### Illustration of loaded Drum for standard test.



# **PROGRAM TABLE**

The following table lists the power consumption and duration for several programs. The table shows the effect on drying parameters at varying spinning speeds during the washing cycle. Actual consumption can vary depending on the room temperature, humidity, load, changes in power supply, and selected options.

The following requirements apply to the consumption values specified below.

Inlet air temperature	room temperature
Inlet air humidity	50–60%
Drying temperature	Normal

Program	Amount	Spinning speed (rpm)	Power consumption, approximately (kWh)	Program duration, approximately (h:min)
Auto normal dry	$\bigcirc$	1000	4,71	2:40
	$\ominus$	1400	2,63	1:45
	$\bigcirc$	1400	2,35	1:25
Auto iron dry	$\bigcirc$	1000	3,80	2:10
	$\ominus$	1400	2,70	1:25
	$\bigcirc$	1400	2,35	1:10
Auto synthetics	$\bigcirc$	1000	1,54	0:55

$\bigcirc$	Full load
$\ominus$	Partial load
$\bigcirc$	Small load

# DISPOSAL

### Disposal / recycling of packaging



Our product packaging is made of environmentally friendly materials that can be recycled, disposed of, or destroyed without any hazard to the environment. To this end, packaging materials are labelled appropriately.


The symbol on the product or its packaging indicates that the product should not be treated as normal household waste. The product should be taken to an authorized collection centre for waste electric and electronic equipment processing.

When disposing of an appliance at the end of its useful life, remove all power cords and destroy the door latch and switch to prevent the door from locking or latching (child safety).

Correct disposal of the product will help prevent any negative effects on the environment and health of people which could occur in case of incorrect product removal. For detailed information on removal and processing of the product, please contact the relevant authority in charge of waste management, your waste disposal service, or the store where you bought the product.

# QUICK GUIDE

X



We reserve the right to modifications.



www.asko.com



TD75.B2 SPK H1 AU/NZ