



### WOOD FLOOR INSTALLATION

1. Drill a 25mm hole in the required position through the floor.
2. Connect G 1/2" Threaded Tail to water supply and ensure tail protrudes above the floor between 21mm and 28mm.
3. Tighten Mounting Plate onto threaded tail and mark hole positions for Screw Toggles. Remove Mounting Plate and drill holes, now re-install Mounting Plate and fasten using the Screw Toggles provided.
4. Push Floor Spout onto the Mounting Plate and fasten Grub Screws using the 2.5mm Allen Key provided.
5. Remove aerator with key provided and flush system to remove all debris.
6. Re-install aerator.




### CONCRETE FLOOR INSTALLATION

1. Drill a 25mm hole in the required position through the floor.
2. Connect G 1/2" Threaded Tail to water supply and ensure tail protrudes above the floor between 21mm and 28mm.
3. Tighten Mounting Plate onto threaded tail and mark hole positions for Masonry Anchor Bolts. Remove Mounting Plate and drill holes, now re-install Mounting Plate and fasten Masonry Anchor Bolts.
4. Push Floor Spout onto the Mounting Plate and fasten Grub Screws using the 2.5mm Allen Key provided.
5. Remove aerator with key provided and flush system to remove all debris.
6. Re-install aerator.



### MOUNTING KIT


4 x Masonry Anchor Bolts



4 x Screw Toggles



1 x 2.5mm Allen Key



recommended  
working pressure  
**150-500  
KPa**



maximum hot  
water temperature  
**75  
degrees**

### NOTE:

- If the pressure exceeds or is likely to exceed 550kpa, an approved pressure limiting device must be installed.
- Flush out all pipe work prior to installation.
- If the water temperature exceeds 75°C, an approved tempering valve must be fitted.
- Installation should comply with Australian standard AS3500.1 or relevant local authority requirements. Showers may not be suitable for use within:
  - Gravity-fed water systems
  - Some instantaneous hot water systems; or

- Pressure supply less than 150kPa;  
NOTE: The 500kPa maximum water supply pressure does not apply to fire service outlets.

Failure to comply with the above may void all warranties.

### WARRANTY:

Please refer to the full warranty statement enclosed with the product before installing. Or visit [www.phoenixtapware.com.au](http://www.phoenixtapware.com.au) to download a copy.

### MAINTENANCE AND CARE:

- Products should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.

### DISCLAIMER:

While we aim to ensure the specifications shown are correct at the time of printing, Phoenix Tapware reserves the right to make modifications without prior notice. Always use the physical product measurements for mark-ups and roughing-in as the line drawing shown may differ from the actual product over time.

\*All measurements are shown in millimeters.