

14cm Built-in warming drawer with adjustable temperature, push to open with soft closing drawer and fan assisted heat circulation.





# **Product Details**

FEATURES			
Adjustable temperature between 40-80C	Push to open, soft closing drawer	Fan forced heating	Quick set function
Full drawer extension	Electronic touch controls		
BENEFITS			
Absolute heat control With five temperature selections between 40C and 80C and three separate functions, you can heat everything from delicate glassware to heavy cookware.		Effortless to use With a push-to-open, soft closing drawer and full drawer extension, youll love how simple it is to use especially when your hands are full. For added safety, it also stops heating automatically when the drawer is open.	
Say goodbye to cold dishes. Ensure your delicious dishes are ready for serving with one of our warming drawers. They complement our compact built-in appliances beautifully.			uilt in combi microwave to allow r conventional, full-sized oven so your kitchen.



# **Specifications**

### PRODUCT PROFILE

Domestic warranty details (yrs)

Туре

compact oven

2

### FEATURES

Features

Cups & Glass warming (40d °C),Plate Warming (60d °C),Fan air circulation,On/Off LED,Anti-slip mat,Adjustable temperature range 40-80°C,Operating indicator light ,Thermal cut out,Overheat protection

# EXTERIOR

Exterior Finish	Dark stainless steel
Push to open drawer system	yes
Cabinet finish	stainless steel
Installation	Built in
Soft close door	Yes

### **SPECIFICATIONS**

Power	Plug
Maximum Power Rating (W)	1000

### DIMENSIONS

#### PRODUCT

Total height (mm)

141

### FLUSH

Cut out height (mm)	141	
Cut out width (mm)	600	

# Electrolux

# EWD1402DSD

Total width (mm)	595	Cut out depth (mm)	541
Total depth (mm)	541		

# SHIPPING

Shipping Volume (m3)	0.10
Shipping Weight (Kg)	21.0
Pack dimensions height	210
Pack dimension width	705
Pack dimension depth	675


# STUFFING QUANTITIES

20ft	297
40ft	594
40ft HC	594





# Dimensions



Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.



# **Terms and Conditions**

#### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

#### **PRODUCT INFORMATION**

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

#### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067 email: customercare@electrolux.com.au web: www.electrolux.com.au

#### ELECTROLUX HOME PRODUCTS NEW ZEALAND telephone: 09 573 2230 fax: 09 573 2221 email: customercare@electrolux.co.nz web: www.electrolux.co.nz