



**1** Position Diverter Body in preferred location. Ensure Rail is level and mark positions of holes.

Shower Wall Outlet Hole Ø25mm

450-650mm Adjustment

600-650mm Recommended

32mm

Apply Teflon Tape

Push Dress Ring over G1/2 Thread.

Screw threaded adaptor to wall outlet. Tighten firmly with spanner.

**2**

Locate Bottom Pillar to desired position.

Screw Hose to Shower Rail with care.

**3**

**For fixing to brick walls with hard plaster or ceramic tiled surface:**

Using a 6mm masonry drill bit, drill holes 30mm deep. Press plugs into holes. Guide Self Tapping Screws through the Mounting Plate, into the plastic plugs and tighten with screwdriver.

**For fitting to stud walls clad with wallboard, with or without ceramic tiles:**

Using a 10mm drill bit, drill through to wall cavity. Remove Screws from Spring Toggles. Guide Screws through the Mounting Plate, screw on the Spring Toggles and push them into the holes. Tighten with screwdriver.

**4**

Grub Screw

Push Lower Dress Ring over wall adaptor. Locate and Push Shower Rail Assy with Hose onto wall adaptors. Tighten grub screws firmly with allen key provided.

Grub Screw

**5**

Flow Restrictor

Rubber Washer

Insert washers and flow restrictor as shown into Shower Rose. Screw Shower Rose to arm with care, ensuring the flow restrictor is not damaged.

**6**

Insert washers and flow restrictor as shown into Shower Hose. Screw Shower Hose Cone to Hand Shower

Rubber Washer

Flow Restrictor

Test and check for leaks



recommended working pressure  
**150-500 KPa**



maximum hot water temperature  
**75 degrees**

**NOTE:**

- If the pressure exceeds or is likely to exceed 550kpa, an approved pressure limiting device must be installed.
- Flush out all pipe work prior to installation.
- If the water temperature exceeds 75°C, an approved tempering valve must be fitted.
- Installation should comply with Australian standard AS3500.1 or relevant local authority requirements. Showers may not be suitable for use within:
  - Gravity-fed water systems
  - Some instantaneous hot water systems; or

- Pressure supply less than 150kPa; NOTE: The 500kPa maximum water supply pressure does not apply to fire service outlets.

Failure to comply with the above may void all warranties.

**WARRANTY:**  
Please refer to the full warranty statement enclosed with the product before installing. Or visit [www.phoenixtapware.com.au](http://www.phoenixtapware.com.au) to download a copy.

**MAINTENANCE AND CARE:**

- Products should be cleaned with mild liquid detergent or soap and water.
- Do not use cream cleaners or citrus based cleaning products, as they are abrasive.
- Use of unsuitable cleaning agents may damage the surface. Any damage caused in this way will not be covered by warranty.

**DISCLAIMER:**  
While we aim to ensure the specifications shown are correct at the time of printing, Phoenix Tapware reserves the right to make modifications without prior notice. Always use the physical product measurements for mark-ups and roughing-in as the line drawing shown may differ from the actual product over time.

\*All measurements are shown in millimeters.

(03) 9780 4200  
[www.phoenixtapware.com.au](http://www.phoenixtapware.com.au)